

# Operating Instructions - Twist-To-Lock Foot Ring




Figure 1 - Loosen Foot Ring





Figure 2 - Tighten Foot Ring



Detail A - Adjust Foot Ring Height

## Foot Ring Adjustment

1. To adjust the twist-to-lock foot ring, first the foot ring must be loosened. Firmly hold the 5-blade base so it does not rotate and turn the foot ring counter-clockwise less than  $\frac{1}{8}$  of a turn. Once it is loose, push down on the black center collar to release the foot ring from its location (Figure 1).
2. The foot ring is now free to move up or down the cylinder. Position the foot ring at a desired location and hold in place while going on to the next step (Detail A).
3. To lock the foot ring in place, push down on foot ring and allow the black center collar to raise up. Then while holding the 5-blade base, turn the foot ring clockwise slowly less than  $\frac{1}{8}$  of a turn until engagement is felt and foot ring is snug. Do not over-tighten or under-tighten as poor function or damage can occur (Figure 2).